Original Post and thread here ->http://forum.xda-developers.com/showthread.php?t=1202666

Here is the instructions provided by xda member **Yay 4 Juggs** created for updating your Motorola Photon 4G. It is being reproduced here with images for those that like to follow steps with images. The OP does not take responsibility for the release, nor create it, nor is the source of it, he is merely providing the update and the instructions.

Images and additional notes provided by twospirits

NOTE: All images in this step by step when clicked open up in another window in full size.

Please donate to the <u>original OP</u> with the <u>Donate to me</u> button, if you find these instructions helpful, if you are willing. It would just be a thank you for these instructions.

PLEASE NOTE: You will lose root but can easily get it back again!!!

Requirements:

Item needed	Notes
RSD Lite and Drivers	RSD Lite is a firmware-flashing application by Motorola. (RSD stands for Remote Software Download.) More info here.
	This zip file includes both the RSD Lite application and the Motorola 32bit
	drivers.
Motorola 64 bit Drivers	Motorola End User Driver Installation for 64 bit systems
Final Release SBF	The 1FF-sunfire-user-2.3.4-4.5.1A-1_SUN-154-CM-Release-keys-signed-Sprint-US.sbf.gz
	update file

Steps:

1.	Download and Install RSD Lite & Driver package from link above.		
2.	Download the SBF file above and extract it to your PC/Laptop.		
3a.	On your phone, Power down your Phone.	Place agains Flore agains Silent mode Arrigan mode Agrian mode Agrian mode O Power off	
3b.	Hold Volume up and Power button	Hold Both Buttons	

3c.	You will see the "Starting RSD protocol support message	Starting RSD protocol support
4.	Launch RSD Lite from your program menu on your pc/laptop	RSD Lite v5.3.1 Multi-Flash / Multi-Flex Tool
5.	Press the "" button next to the box labeled "Filename"	Codig 14ds Flacer Codig
6.	Load the SBF file you extracted from the MR download.	The Control
7.	Plug your device into your computer RSDLite should recognize your phone right away if you installed the drivers from this link I provided	Control No. 1 No.
8.	Press the Start button RSD Lite will then start updating the firmware. Be patientIt will take a whileand will reboot a couple of times so grab a beverage of choice use the restroom, take out the dog, whatever.	Corfs 1-Ma Paris Marie Paris
9.	You may require reactivation again mine did so be sur so,webphone to call Sprint for programming, MSL co	

